

## 一般用ドットゲージ (きょう雑物測定図表)

Designed by オフィス・テッド  
 参考規格 JIS P8208/P8145  
 OTG001-ver08(2110)1J3A

Square measure	Width	mm
0.05mm <sup>2</sup>	0.10mm	0
0.10mm <sup>2</sup>	0.15mm	0
0.15mm <sup>2</sup>	0.20mm	0
0.20mm <sup>2</sup>	0.25mm	10
0.30mm <sup>2</sup>	0.30mm	10
0.40mm <sup>2</sup>	0.35mm	20
0.50mm <sup>2</sup>	0.40mm	20
0.70mm <sup>2</sup>	0.45mm	30
1.00mm <sup>2</sup>	0.50mm	30
1.50mm <sup>2</sup>	0.60mm	40
2.00mm <sup>2</sup>	0.70mm	40
2.50mm <sup>2</sup>	0.80mm	50
3.00mm <sup>2</sup>	0.90mm	50
	1.00mm	60

## 精密用ドットゲージ (きょう雑物測定図表)

Designed by オフィス・テッド  
 参考規格 JIS P8208/P8145  
 OTG002-ver08(2110)1J3A

Square measure	Width	mm
0.01mm <sup>2</sup>	0.10mm	0
0.02mm <sup>2</sup>	0.15mm	0
0.03mm <sup>2</sup>	0.20mm	0
0.04mm <sup>2</sup>	0.25mm	10
0.05mm <sup>2</sup>	0.30mm	10
0.10mm <sup>2</sup>	0.35mm	20
0.15mm <sup>2</sup>	0.40mm	20
0.20mm <sup>2</sup>	0.45mm	30
0.30mm <sup>2</sup>	0.50mm	30
0.40mm <sup>2</sup>	0.60mm	40
0.50mm <sup>2</sup>	0.70mm	40
0.60mm <sup>2</sup>	0.80mm	50
0.70mm <sup>2</sup>	0.90mm	50
	1.00mm	60